
1, setting snapshot function




2 Setting video motion




click "Enable" and set motion dection "Region' and "Period". Then click "Snapshot" and type of alarm "show message/ buzzer/ send email/ FTP"

3 setting email alarm



If you want to set email alarm, you need use the email which also support smtp. And please note, different email have different port. Some email address don't support "SSL", you need not choose "SSL".

4, settiing FTP alarm



If you are not clear your FTP server information, you may contact your supplier of FTP server.